

Glass Renovating Powder




Product Usage Guide

Professional

BB093-2



Manual Wash



1 Use appropriate PPE as indicated in COSHH/REACH data.



2 Dilute 50g powder to 5 litre hot water.




3 Wash the glasses in the normal way and rinse thoroughly.


Cleaning Cabinet Glasswash Machine




1 Use appropriate PPE as indicated in COSHH/REACH data.



2 Bring the machine up to the operating temperature and add 100g of powder to the wash water.



3 Wash the glasses in the normal way.



4 After 3 or 4 cycles add an extra 50gm of powder to maintain concentration.

Health & Safety

Please refer to relevant COSHH Safety Data Sheet



Scan for further product details



Do not use on any aluminium products.

www.jangro.net